

Merseyrail :

Hunts Cross

To Hunts Cross

Location :	Speke Road
Comments :	Stop in bus stop opposite the station. (Bus stop outside COOP can be used for drop off if running into Speke depot)
Risk Issue :	Standard bus stop

Layby Bus Stop



To Liverpool

Location :	Speke Road
Comments :	Stop in bus stop opposite the station
Risk Issue :	Standard bus stop

Layby Bus Stop



Merseyrail : Liverpool South Parkway

To Hunts Cross

Location :	Bus Station Stand 1
Comments :	First bus stop as you enter the bus station
Risk Issue :	Standard bus stop


Layby Bus Stop



To Liverpool

Location :	Bus Station Stand 1
Comments :	First bus stop as you enter the bus station
Risk Issue :	Standard bus stop

Layby Bus Stop



Merseyrail : Cressington

To Hunts Cross

Location :	St Marys Road
Comments :	Stop in bus stop outside Coast Cycle shop
Risk Issue :	Standard bus stop

Layby Bus Stop



To Liverpool

Location :	St Marys Road
Comments :	Stop in bus stop outside church
Risk Issue :	Standard bus stop

Layby Bus Stop




Merseyrail :

Aigburth

To Hunts Cross

Location :	Aigburth Road
Comments :	Stop in layby bus stop just after Mersey Road Traffic lights
Risk Issue :	Standard bus stop



To Liverpool

Location :	Aigburth Road
Comments :	Stop in layby bus stop outside shops just after Mersey Road Traffic lights
Risk Issue :	Standard bus stop



Merseyrail : St Michaels

To Hunts Cross

Location :	Aigburth Road
Comments :	Stop in bus stop outside Churrasco Resteraunt
Risk Issue :	Standard bus stop



To Liverpool

Location :	Aigburth Road
Comments :	Stop in bus stop outside Tesco Express
Risk Issue :	Standard bus stop



R RAIL REPLACEMENT
BUS STOP

LIVERPOOL CITY CENTRE
HUNTS CROSS

M Merseyrail

Merseyrail :

Brunswick

To Hunts Cross

Location :	Brunswick Station
Comments :	Bus stop inside station turnaround nearest to the station
Risk Issue :	Standard bus stop

Layby Bus Stop



To Liverpool

Location :	Brunswick Station
Comments :	Bus stop inside station turnaround nearest to the station
Risk Issue :	Standard bus stop

Layby Bus Stop



R RAIL REPLACEMENT
BUS STOP

M Merseyrail


Merseyrail :

Moorfields

To Wirral / Southport / Ormskirk / Kirkby

Location :	Moorfields
Comments :	Stop outside station by bollards
Risk Issue :	No bus stop: Use caution when pulling away due to bollards on kerb

No Bus Stop



To Liverpool

Location :	Moorfields
Comments :	Stop outside station by bollards
Risk Issue :	No bus stop: Use caution when pulling away due to bollards on kerb

No Bus Stop

